



QUICK REFERENCE SHEET

This reference sheet should only be used as a starting guide.
Experimentation is the best way to determine which setup works best.

AIR CAP SET INFORMATION FOR FUJI SPRAY HVLP SYSTEMS																											
PART #	MODEL	SIZE	FORD #4 RUNOUT TIME (in seconds)	OUTPUT	Fine Finishing							Automotive				Other											
					Dye / Ink	Shellac / Stain	Sanding Sealer	Clear Lacquer	Varnish	Polyurethane	Pigmented Lacquer	Clear	Base	Primer	Flake Additives	Bathtub Coatings	Oil-based Primers	Oil-based Paints	Waterborne Primers	Waterborne Paints	Multi-fleck Finishes						
8050-2	GXPC	0.7mm	8 or less	Fine	●	●																					
7020-1	M	0.8mm																									
5100-1	T																										
8050-3	GXPC	1.0mm	8-21	Fine to Medium		●	●	●	●	●		●		●													
7020-2	M	1.0mm	8-17																								
5100-2	T																										
7020-3	M	1.3mm*	17-25	Medium			●	●	●	●		●		●													
5100-3	T																										
8050-4	GXPC	1.4mm*	21-31										●														
7020-4	M	1.5mm	25-37	Medium to High						●				●													
5100-4	T																										
8050-5	GXPC	1.8mm	31-60	High									●	●													
7020-5	M		37-50																								
5100-5	T																										
7020-6	M	2.0mm	50-80	High									●														
5100-6	T																										
8050-6	GXPC	2.2mm	60 or more	Extra High																							
5100-7	T	2.5mm	80 or more																								

*Standard Air Cap set